MR-GU3M2P monitoring relays



Output circuit - contact data

- Multifunctions monitoring relays (AC voltage monitoring in 3-phase network) Monitoring of phase sequence and phase failure
- Detection of reverse voltage by means of asymmetry Connection of neutral wire (optional)
- Supply voltage = monitoring voltage Output: 2 CO (2 changeover contacts) Industrial cover, width 22,5 mm
- Direct mounting on 35 mm rail mount acc. to EN 60715
- Recognitions, certifications, directives: RoHS, CE

Number and type of contacts	2 CO
Rated voltage	250 V AC
Max. breaking capacity AC	1 750 VA (3 A / 250 V AC) • 1 250 VA (5 A / 250 V AC) •
Max. operating frequency	
 at resistive load 100 VA 	3 600 cycles/hour
 at resistive load 1 000 VA 	360 cycles/hour
Input circuit	
Supply voltage	= monitoring voltage terminals (N)-L1-L2-L3
Must release voltage	AC: ≥ 0,2 U _n
Operating range of supply voltage	3(N)~ 342457 V
Rated power consumption A	C 9,0 VA
Range of supply frequency A	C 4863 Hz
Duty cycle	100%
Measuring • measured value	AC sinus, 4863 Hz
circuit • measuring inputs	AC: 3(N)~ 400/230 V terminals (N)-L1-L2-L3
 overload capacity 	3(N)~ 457/264 V
 input resistance 	3(N)~ 400/230 V: 15 kΩ
 asymmetry 	fixed: typical value 30%
Insulation according to EN 60664-1	
Rated surge voltage	4 000 V 1,2 / 50 μs
Overvoltage category	
Insulation pollution degree	3
General data	
Electrical life • resistive AC1	> 2 x 10 ⁵ 1 000 VA
Mechanical life (cycles)	> 2 x 10 ⁷
Dimensions (L x W x H)	90 x 22,5 x 108 mm
Weight	100 g
Ambient temperature • storage	-25+70 °C
(non-condensation and/or icing) • operating	g -25+55 °C
Cover protection category	IP 20 EN 60529
Relative humidity	1585%
Shock resistance	15 g 11 ms
Vibration resistance	0,35 mm DA 1055 Hz
Meassuring circuit data	
Functions	SEQ - monitoring of phase sequence and phase failure
	ASYM - detection of reverse voltage by means of asymmetry
	connection of neutral wire (optional)
Range of delay timing adjustment	start-up suppression: fixed, max. 0,5 s
	tripping delay: fixed, max. 0,35 s
Recovery time	100 ms
LED indicator	green LED U ON - indication of supply voltage U
	yellow LED R ON/OFF - output relay status

• If the distance between the relays mounted side by side is less than 5 mm. • If the distance between the relays mounted side by side is greater than 5 mm.

1

MR-GU3M2P monitoring relays

Functions

SEQ - Phase sequence monitoring.



When all the phases are connected in the correct sequence and the measured asymmetry is less than the fixed value, the output relay R switches into on-position (yellow LED illuminated). When the phase sequence changes, the output relay R switches into off-position (yellow LED not illuminated).

SEQ - Phase failure monitoring.



The output relay R switches into off-position (yellow LED not illuminated), when one of the three phases fails.

ASYM - Detection of reverse voltage by means of asymmetry.



The output relay R switches into off-position (yellow LED not illuminated) when the asymmetry between the phase voltages exceeds the fixed value of the asymmetry. An asymmetry caused by the reverse voltage of a consumer (e.g. a motor which continues to run on two phases only) does not effect the disconnection.

U - supply voltage; R - output state of the relay; L1, L2, L3 - phases

Front panel description



Connection diagram



2

MR-GU3M2P monitoring relays



Relays **MR-GU3M2P** are designed for direct mounting on 35 mm rail mount acc. to EN 60715. Operational position - any. **Terminals** - **cross section of the connection cables**: $1 \times 0.5 \dots 2.5 \text{ mm}^2$ with/without multicore cable end, $1 \times 4 \text{ mm}^2$ without multicore cable end, $2 \times 0.5 \dots 1.5 \text{ mm}^2$ with/without multicore cable end, $2 \times 2.5 \text{ mm}^2$ flexible without multicore cable end.

Ordering codes



Example of ordering code:

MR-GU3M2P

monitoring relay **MR-GU3M2P**, multifunction (relay perform 2 functions), industrial cover, width 22,5 mm, two changeover contacts, rated input voltage (supply): AC - 3(N)~ 400/230 V

PRECAUTIONS:

1. Ensure that the parameters of the product described in its specification provide a safety margin for the appropriate operation of the device or system and never use the product in circumstances which exceed the parameters of the product. 2. Never touch any live parts of the device. 3. Ensure that the product has been connected correctly. An incorrect connection may cause malfunction, excessive heating or risk of fire. 4. In case of any risk of any serious material loss or death or injuries of humans or animals, the devices or systems shall be designed so to equip them with double safety system to guarantee their reliable operation.

3